




SELECTONE APPLICATION NOTE

Connections

TONE UNIT		RADIO	
+ SUPPLY	RED		BASE OF Q716 P2 (FTC 5)
-SUPPLY	BLACK		
DECODE LATCH	WHITE/ORANGE		
TONE INPUT	GREEN		
MONITOR/RESET	BROWN		
NOTES		MODIFICATIONS	
<p>THIS INSTALLATION CAUSES TX INHIBIT UNTIL PROPER BURST TONE IS RECEIVED. RESET OF DECODER IS AUTOMATIC AT THE END OF TX DROP-OUT DELAY. TO BY-PASS BURST TONE REQUIREMENT, APPLY +VDC TO WHITE WIRE.</p>		<p>TONE UNIT: PLACE JU1 CENTER TO "A". CLIP R24. ADD 10K IN SERIES WITH BROWN WIRE.</p>	
		<p>RADIO:</p>	
<p>This is a recommended installation procedure for SELECTONE equipment based on the best information available to us at the time of publication; however, SELECTONE assumes no responsibility for the accuracy of the information or for any damage to the radio, tone unit, or other associated equipment resulting from the use of this procedure.</p>			

JNS
 APPLICATION NO. 1188
 U.F.O. 7/1/83
 BURST TONE DECODE
 TONE MODEL NO. ST-120
 REGENCY MCCU-15R A/B