## SELECTONE APPLICATION NOTE

Connections			SNC
TONEUNIT		RADIO	
_ST WHITE/ORANGE BROWN RED BLACK GREEN	DECODE LATCH MONITOR/RESET + SUPPLY - SUPPLY TONE INPUT	J906 G.E. CENTURY II  4  5  8  9 10	2/21/84   196
			BURST TONE DECODE
N	OTES	MODIFICATIONS  TONEUNIT: PLACE JU1 CENTER TO 'B'. USE WHITE/VIOLET AND BLACK/ORANGE WIRES AS REQUIRED. REMOVE AND JUMPER VR1.	TONE MODEL NO. ST-120
SELECTONE equipmention available to us at the ever, SELECTONE assuraccuracy of the information.	d installation procedure for the based on the best information; however, the time of publication; however, and the time of publication or the tion or for any damage to the other associated equipment this procedure.	RADIO: Use G.E. "Channel Guard" TYPE HOOKSWITCH.	RADIO MODEL: G.E. CENTURY II