	CONNECTIONS TONE UNIT		RADIO
0	P.T.T. (ENC. ENABLE)	YELLOW	> P401-2 KEYED FILTERED A+
0	ENCODE OUTPUT	WHT/GRN	 > P401-6 "PL" TONE
0	MONITOR	BROWN	,
0	(-) SUPPLY	BLACK	 *> P201-1 GROUND
0	HI PASS FILTER OUT	WHT/BLU	 > P201-6 "PL" FILTER OUTPUT
0	TONE INPUT	GREEN	 > P201-8 "PL" FILTER INPUT
0	(+) SUPPLY	RED	*> P201-9 +9.6V CONTINUOUS
0	DECODE (-)	WHT/ORG	*> P201-5 DECODER OUTPUT
	======================================		RADIO
USER: MOUNT THE TONE UNIT IN T VICINITY OF THE AUDIO/SQUELCH REMOVE THE UNUSED WIRES. FACTORY: NONE.			<pre>THIS APPLICATION APPLIES TO TRN6006A OR TRN6007A AUDIO &amp; SQUELCH BOARD. REMOVE JU201 AND JU202. ADD A 10 RESISTOR FROM P201-5 TO P201-9 P401 is located on the EXCITER board. MAKE SURE JU204 IS IN. P201 is located on the AUDIO &amp; SQUELCH board. ON STATION CONTROL BOARD JU9 IS</pre>